

C1 Loco 7326

Owner's handbook

Time on your side

Your C1 Loco 7326 has been designed in England and handbuilt in Switzerland by highly talented craftspeople. This ensures not only accurate and precise timekeeping, but also brings a real pride of ownership that only watches of the highest quality standards can hope to deliver.

You have made an investment, a good one, and the aim of this handbook is to help you make the most of that investment in what we hope will be a lifetime of ownership.

Mike France

CEO & co-founder



 **Christopher
Ward**



The features and technical details of your C1 Loco 7326

- Swiss made
- Limited edition of 10 pieces
- Hand-wound mechanical in-house Calibre CW-003
- 144 hours power reserve
- Polished and linear-brushed 904L stainless steel case
- Anti-reflective box sapphire crystals on front and exhibition caseback
- Embossed push-in crown
- Finely grained base dial with engraved Union Jack motif
- Domed, high-polish lacquer dial
- Dial-side aperture showcasing the free-sprung balance and escapement
- Diamond-polished hands
- Eco-friendly luxury presentation case with owner's handbook

Calibre:	Calibre CW-003
Jewels:	29
Frequency:	28,800 vph (4Hz)
Power reserve:	144 hours
Movement:	Hand-polished movement bridges with refined finishing
Timing tolerance :	-0/+7 secs per day
Material:	904L Stainless steel
Diameter/Weight:	41mm : 64.32g
Height:	14.10mm
Water resistance :	3 ATM (30 meters)
Strap width:	22mm

Setting the time


Wind in a clockwise direction to re-power the watch in Position 1.

To wind the movement from empty to full power turn the crown clockwise, approximately 95 times. You will feel strong resistance when fully wound.

When fully wound, your C1 Loco 7326 has a maximum power reserve of 144 hours.

Pull the crown gently into Position 2. This position is used for handsetting.

For precise time setting, we recommend passing beyond the desired minute and setting the hand backwards.






Changing your strap

- 1 Locate the quick-release pins on the underside of your case. Pinch the pins inwards to detach.
- 2 To reattach your strap, pinch the pins inwards, and align the spring bars so they click securely into the lug holes on either side of the strap or bracelet.

Detaching and reattaching a strap





Servicing your watch

Our approach to service is about uncompromised quality and great value for money. The process, led by our expert technicians, won't cost the earth and will have the watch back on your wrist in reasonable time. We recommend you service your watch every three to four years to keep it in peak condition.





Your 60|60 Guarantee

Your Christopher Ward watch is covered by our industry-leading 60|60 Guarantee.

This means that you can return it 60 days after purchase and receive a full refund (as long as the watch is in perfect condition).

And if your watch develops a mechanical fault within five years (60 months), we'll repair it for free. Please use the warranty card opposite to arrange this.

If you ever need to get hold of us we're at your service. And if you'd like to explore the CW world more, you can follow us on social media.



ChristopherWardLondon



@chriswardlondon