



C63 Sealander Rocks LE

Owner's handbook



Time on your side

Your C63 Sealander Rocks LE watch has been designed in England and handbuilt in Switzerland by highly talented craftspeople. This ensures not only accurate and precise timekeeping, but also brings a real pride of ownership that only watches of the highest quality standards can hope to deliver.

You have made an investment, a good one, and the aim of this handbook is to help you make the most of that investment in what we hope will be a lifetime of ownership.

Mike France
CEO & co-founder



 **Christopher
Ward**



The features and technical details of your C63 Sealander Rocks LE

- Swiss made
- 26 jewel self-winding mechanical movement
- 38 - 41 hour power reserve
- Twin-flag engraving over 'Colimaçoné' finish on the rotor
- Elaboré 'Colimaçoné' finish on the movement
- Brushed and polished marine-grade stainless steel case
- Stamped crown with sandblasted lower area and polished top
- Screw down display caseback
- Unique engraved serial number
- Central hacking seconds
- Unique and natural stone dial, limited to 150 pieces per stone
- Indexes with diamond polished facets
- Super-LumiNova® Grade X1 BL C1-filled hands only


Technical details

Calibre	Sellita SW200-1
Case	Stainless steel
Diameter	36mm
Height	11.40mm
Lug to lug	42.87mm
Weight	54g
Water resistance	15 ATM (150)
Vibrations	28,800 per hour (4Hz)
Tolerance	-20/+20 seconds per day
Power reserve	38 - 41 hours
Strap width	20mm

Setting the time

Unscrew the crown* anti-clockwise from the case to position 2 for winding in power. Wind in a clockwise direction to re-power the watch.

Pull gently into position 3. This position is used for handsetting and stopping of the seconds hand. For precise time setting it is recommended to pass beyond the desired minute and to set the hand backwards.




*The screw-down crown should sit flush to the case (position 1) in order to maintain water resistance.




Changing your strap

- 1 Locate the quick-release pins on the underside of your case. Pinch the pins inwards to detach.
- 2 To reattach your strap or bracelet, pinch the pins inwards, and align the spring bars so they click securely into the lug holes on either side of the strap or bracelet.

Detaching and reattaching a strap







Detaching and reattaching a bracelet



Using the micro adjustment on your bracelet

- 1 Press buttons to release.
- 2 Pull open the clasp.
- 3 There are three micro adjustment positions, which allows for a maximum extension of 6mm. To extend, pull the lever to unlock and simultaneously pull on the bracelet into the desired position.
- 4 To shorten, simply pull the lever to unlock and push the bracelet back into the clasp.



Servicing your watch

Our approach to service is about uncompromised quality and great value for money. The process, led by our expert technicians, won't cost the earth and will have the watch back on your wrist in reasonable time. We recommend you service your watch every three to four years to keep it in peak condition.



Your 60|60 Guarantee

Your Christopher Ward watch is covered by our industry-leading 60|60 Guarantee.

This means that you can return it 60 days after purchase and receive a full refund (as long as the watch is in perfect condition).

And if your watch develops a mechanical fault within five years (60 months), we'll repair it for free. Please use the warranty card opposite to arrange this.

If you ever need to get hold of us we're at your service. And if you'd like to explore the CW world more, you can follow us on social media.



ChristopherWardLondon



@chriswardlondon