

## C63 Sealander GMT Extreme

Owner's handbook

## Time on your side

Your C63 Sealander GMT Extreme watch has been designed in England and handbuilt in Switzerland by highly talented craftspeople. This ensures not only accurate and precise timekeeping, but also brings a real pride of ownership that only watches of the highest quality standards can hope to deliver.

You have made an investment, a good one, and the aim of this handbook is to help you make the most of that investment in what we hope will be a lifetime of ownership.

**Mike France**

CEO & co-founder



 Christopher  
Ward



## The features and technical details of your C63 Sealander GMT Extreme

- Swiss made
- Self-winding 25 jewel mechanical movement
- Deep stamped Globe 3D effect, brushed and sandblasted
- Rugg brushed finish stainless steel case
- Bead blasted ceramic bezel filled with numbers Super-LumiNova® GL Grade X1
- GMT complication
- Embossed screw-down crown
- Anti-reflective sapphire crystal
- Internal rubber shock absorber protecting the movement from hard impact
- Date calendar same color as dial
- Matt texture finish dial and dial ring
- 3D Globolight™ indexes and applied logo Super-LumiNova® BL Grade X1
- Matt black hour and minute hand with 3D Globolight™ Super-LumiNova® BL Grade X1
- Matt black and orange GMT hand with Super-LumiNova® GL Grade X1
- Rugged brushed Bader bracelet with micro-adjustable ratchet clasp
- Nylon textile strap with Velcro® loop buckle

|                  |                                 |
|------------------|---------------------------------|
| Calibre          | Sellita SW330-2                 |
| Case             | Stainless steel & ceramic bezel |
| Diameter         | 41 mm                           |
| Height           | 12.05mm                         |
| Weight           | 73g                             |
| Water resistance | 15 ATM (150 metres)             |
| Vibrations       | 28,800 per hour (4Hz)           |
| Timing tolerance | -20/+20 seconds per day         |
| Lug to lug       | 48mm                            |
| Strap width      | 22mm                            |
| Power reserve:   | 50-56 hours                     |

## Setting the time, date and GMT hand


Unscrew the crown\* anti-clockwise from the case to position 2 for winding in power. Wind in a clockwise direction to re-power the watch.

To set the date pull gently into position 3 and turn in an anti-clockwise direction.

To set the GMT hand, turn the crown clockwise and rotate the hand until you have reached the desired time indication. The GMT hand moves in one-hour increments.

Pull gently into position 4. This position is used for handsetting and stopping of the seconds hand. For precise time setting it is recommended to pass beyond the desired minute and to set the hand backwards.

\*The screw-down crown should sit flush to the case (position 1) in order to maintain water resistance.



Date correction should not be carried out between 20:00 hrs to 2:00 hrs as the watch gearing will already be aligning itself to change the date.


## Using the GMT hand for travel

Set the time in your new destination by pulling the crown into position 4 and move the hour/minute hands until they indicate the desired time.

Push crown into position 3 and wind, clockwise, the GMT hand around the 24-hour scale on the bezel until you have the right time at home. E.g. If you're travelling from London at 12.10 to New York, you would turn the hour/minute hands to 7.10 (New York time is five hours behind London) and wind the GMT hand around to the 12.10 position.

Once set, it means that, for example, you can gauge the time to ring your friends and family without waking them in the middle of the night.

The table below can be used to determine the appropriate time zone when setting the hour/minute hands.







## Changing your strap

- 1 Locate the quick-release pins on your strap or bracelet. Pinch the pins inwards to detach.
- 2 To reattach your strap or bracelet, pinch the pins inwards, and align the spring bars so they click securely into the lug holes on each side.

## Detaching and reattaching a strap




## Detaching and reattaching a bracelet




## Using the micro adjustment on your bracelet

- 1 Press buttons to release.
- 2 Pull open the clasp.
- 3 There are three micro adjustment positions, which allows for a maximum extension of 6mm. To extend, push the button to unlock and simultaneously pull on the bracelet into the desired position.
- 4 To shorten, simply push the button and then slide the bracelet back into the clasp.



1



2



3



4



Your Christopher Ward watch is covered by our 60|60 Guarantee.

This means that you can return it 60 days after purchase and receive a full refund (as long as the watch is in perfect condition).

And if your watch develops a mechanical fault within five years (60 months), we'll repair it for free. Please use the warranty card opposite to arrange this.

If you ever need to get hold of us we're at your service. And if you'd like to explore the CW world more, you can follow us on social media.

 ChristopherWardLondon  @chriswardlondon